



Disarm: User Code + [1]
 Arm Away: User Code + [2]
 Arm Stay: User Code + [3]
 Arm Away or Stay with No Delay: User Code + [2] or [3] + [0]
 Turn on 1-6: [#] + [4] + Dev. No.
 Turn on 7 & 8: User Code + [#] + [4] + Dev. No.
 Turn off 1-6: [#] + [7] + Dev. No.
 Turn off 7 & 8: User Code + [#] + [7] + Dev. No.
 Bypass a zone(s): User Code + [6] + zone no.
 Activate Quick Bypass: User Code + [6] + [#]
 Check system: [1]
 Hang up: User Code + [9]

Remote Phone Control

LYNXR-EN

SYSTEM FUNCTIONS REFERENCE CARD

This card lists the most common user functions. For further information, refer to User Guide.

Security Functions

Check system: **STATUS**
 Arm Stay: Press and hold **STAY** or User Code + **STAY**
 Restart exit delay: **STAY**
 Arm Away: Press and hold **AWAY** or User Code + **AWAY**
 Arm No Delay: Press and hold **AWAY** or **STAY** + **NO DELAY**
 or User Code + **AWAY** or **STAY** + **NO DELAY**
 Disarm & silence alarms: User Code + **OFF**
 Bypass a zone(s): User Code + **BYPASS** + Zone No.
 Chime mode on or off: **FUNCTION** + **CHIME**

Message Center

Record a message: **FUNCTION** + **RECORD**
 Stop recording: **OFF**
 Play back a message: **FUNCTION** + **PLAY**
 Adjust volume: **FUNCTION** + **VOLUME** + [3] or [6]
 Mute announcements: **FUNCTION** + **VOLUME** + **OFF**
 Restore announcements: **FUNCTION** + **VOLUME** + [3]
 Delete all messages: **FUNCTION** + **DELETE** (During message replay)

Speaker Phone Operation

To place or answer a call using the speaker phone: [#] + **AUX**
 Flash (switch between two calls using call waiting): **AUX**
 To hang up: **OFF**
 Enable/disable (toggle) ringer: [#] + **VOLUME** + **AUX**
 Return keypad to telephone mode: [#] + **AUX**

Other Functions

Set the time and date: User Code + **FUNCTION** + [63]
 Add a user code: Master Code + **CODE** + User No. + User Code
 Delete a user code: Master Code + **CODE** + User No.
 Test mode on: User Code + **TEST**
 Test mode off: User Code + **OFF**
 Use the AUX function: Press and hold **AUX** key 2 secs. + User Code
 Send message to pager: Press and hold **AUX** key 2 secs. (if programmed)
 Turn ON/OFF 1-6: **FUNCTION** + **LIGHTS ON** + Dev No. or **LIGHTS OFF** + Dev No.
 Turn ON/OFF 7-8: **FUNCTION** + **LIGHTS ON** + Dev No. or **LIGHTS OFF** + Dev No.
 Program/Delete Follow Me phone number: User Code + **FUNCTION** + [65]

More Information on other side →