



Testing Your Alarm

Once your system is installed the tech will test the system to make sure our central station is receiving the signals. The alarm will be programmed to transmit a weekly test, this tells us that the system is functioning ok. If a missing test signal is detected our central station will notify you of the missing signal.

You should become familiar with how to test your system this could help detect a problem that may be solved easily.

Before you begin a test, make sure you have your pass code

- 1. Call our monitoring station at 405-810-0335*
- 2. Tell the operator that you would like to place your system on test, Do not test your alarm until you have notified the central station.*
- 3. Arm your system in the Away mode if you want to test the motion, otherwise the stay mode is fine.*
- 4. Wait for the exit time to expire, (if testing your motion don't forget to open a exit door or your system will arm in the stay mode.*
- 5. Open a protected door or window, or walk in front of your motion detector until you hear the alarm activate.*
- 6. Allow the siren to run for a minimum of 30 seconds before you turn it off.*
- 7. Call the central station and verify that they received the alarm. (if not, repeat steps 3 - 6 again and make sure you allow your siren to activate for at least 30Sec). If the central station still did not receive a signal you can advise them you need service or you can complete a service request form under our Customer Care center.*